

Installation guide




Cartridge control Type ACB

060R9765

060R9765

HFC, HCFC

Type		Ohmic	FLA	LRA	V
ACB-1UA	SPST-NO	1 A	1 A	6 A	120/240 AC
					250 AC
ACB-1UB	SPST-NC				120/240 AC
					250 AC
ACB-2UA	SPST-NO	8 A	8 A	48 A	120/240 AC
		6 A	6 A	36 A	250 AC
ACB-2UB	SPST-NC	8 A	8 A	48 A	120/240 AC
		6 A	6 A	36 A	250 AC
ACB-4UA	SPST-NO	0.075 A	0.075 A	0.075 A	120/240 AC and 30 DC
					250 AC and 30 DC
ACB-4UB	SPST-NC				120/240 AC and 30 DC
					250 AC and 30 DC
ACB-2UC	SPDT	8 A	8 A	48 A	120/240 AC
		4 A	4 A	24 A	250 AC



en	1: red	4: Blue	2: Black
de	1: Rot	4: Blau	2: Schwarz
fr	1: Rouge	4: Bleu	2: Noir
es	1: Rojo	4: Azul	2: Negro
it	1: Rosso	4: Blue	2: Nero